



TYPE-S

Thin and light protective keyboard case
For Samsung GALAXY Tab S 10.5




Setup Guide

Contents

English	3
-------------------------	-------------------

www.logitech.com/support/type-s


Know your product




Setting up the keyboard case

Getting started


1. Open the keyboard case and push your Samsung GALAXY Tab S 10.5 into the tablet holder:



2. Push your Samsung GALAXY Tab S 10.5 down into the hook:




3. Move the keyboard case into the typing position by lifting the back of the protective case and sliding the hook forwards until it aligns with the magnet:



Connecting your keyboard and tablet

The keyboard case links to your tablet via a Bluetooth connection. The first time you use the keyboard case, you must pair the keyboard with your tablet.



1. Turn on the keyboard:

The status light blinks blue (fast blink) to indicate that the keyboard is discoverable, ready for pairing with your tablet. The first time you turn on the keyboard it remains discoverable for 15 minutes.

If the status light turns red, charge the battery. For more information, see “Charging the keyboard battery.”

2. Make sure your tablet's Bluetooth feature is on.

From a Home screen, touch  **Apps** →  **Settings** → **Network connections** section, and turn on the **Bluetooth switch**.

3. Pair the keyboard case with your tablet.

(i) In your tablet's **Bluetooth** settings page, select “TYPE-S” in the list of **Available devices**.

(ii) When prompted, enter the PIN displayed using the case keyboard.

When successful connection is made, the status light turns solid blue for a short time, and then turns off.


Connecting to another tablet

1. Make sure the keyboard is turned on.

2. Make sure your tablet's Bluetooth feature is on.

From a Home screen, touch  **Apps** →  **Settings** → **Network connections** section, and turn on the **Bluetooth switch**.

3. Press the Bluetooth Connect button:



The status light blinks blue (fast blink) to indicate that the keyboard is discoverable, ready for pairing with your tablet. The keyboard is discoverable for 3 minutes.

4. Pair the keyboard case with your tablet.

(i) In your tablet's **Bluetooth** settings page, select "TYPE-S" in the list of **Available devices**.

(ii) When prompted, enter the PIN displayed using the case keyboard.

When successful connection is made, the status light turns solid blue for a short time, and then turns off.


Using the keyboard case

Two viewing positions

The keyboard case provides two viewing positions—one for typing and another for browsing.


To type:

1. Move the tablet holder into the typing position, aligning it with the built-in magnet to secure it:



Typing position

2. Turn on the keyboard:



If the status light turns red, charge the battery. For more information, see “Charging the keyboard battery.”

If you don't use the keyboard for a while in the typing position, it enters sleep mode automatically. Pressing any key wakes it.

To browse, place the tablet holder in the browsing position:



Browsing position

You can switch off the keyboard if you want to conserve battery power.

Status light indicators

Bluetooth and battery status light

Light	Description
Blinking green	The battery is charging.
Green	The battery is charged (more than 10%).
Red	Battery power is low (less than 10%). Recharge the battery.
Blinking blue	Fast: The keyboard is in discovery mode, ready for pairing. Slow: The keyboard is trying to reconnect to your Samsung GALAXY Tab S 10.5.
Solid blue	Bluetooth pairing or reconnection is successful.

Function keys



FN + Back: Esc



FN + 1: Lock screen
Lock or unlock the tablet screen



FN + 2: Web browser



FN + 3: Mail



FN + 4: Calendar



FN + 5: Music



FN + 6: Previous track



FN + 7: Play/Pause



FN + 8: Next track



FN + 9: Mute



FN + 0: Volume down



FN + -: Volume up



FN + =: Print Screen



FN + Backspace: Forward delete



FN + Tab: Show all apps



FN + Caps Lock:
Quick panel/Notifications



FN + X: Cut



FN + C: Copy



FN + V: Paste



FN + Left cursor: Home



FN + Right cursor: End



FN + Up cursor: Page Up



FN + Down cursor: Page Down



FN + Search: Voice search
Use your voice to send messages, make calls, and more



FN + Right Alt: Android™ menu



FN + Android home: Switch applications




FN + spacebar: Switch language



Note:

- To select a function key, press and hold the FN key, and then press the key indicated above.

Charging the keyboard battery



If the status light is red the keyboard case battery needs to be charged.

1. Plug one end of the micro-USB cable into the charging port, and the other end into a USB port on your computer.


The status light blinks green as the battery charges.

2. Charge the battery until the status light turns solid green.

Battery information

- A fully charged battery provides about three months of use when the keyboard is used about two hours a day.
- Charge the battery if the status light turns red briefly after the keyboard turns on.
- When not in use, turn off the keyboard to conserve battery power.
- The keyboard enters sleep mode automatically if not used for a while in the typing position. Press any key to wake it.

Battery disposal at product end of life




1. Pry off top cover of keyboard with screwdriver.
2. Detach battery from circuit board and remove battery.
3. Dispose of your product and its battery according to local laws.


When you've finished using the keyboard case

Detaching your tablet

1. Release your tablet from the hook:




2. Slide your tablet out of the tab holders:



Your tablet is then released.

Storing your tablet for travel

1. Insert your tablet in the tablet holder.
2. Close the keyboard case:



Visit Product Support

There's more information and support online for your product. Take a moment to visit Product Support to learn more about your new keyboard case.

Browse online articles for setup help, usage tips, and information about additional features.

Connect with other users in our Community Forums to get advice, ask questions, and share solutions.

Find a wide selection of content including:

- Tutorials
- Troubleshooting
- Support community
- Online documentation
- Warranty information
- Spare parts (when available)

Go to:

www.logitech.com/support/type-s

Troubleshooting

The keyboard does not work

- Press any key to wake the keyboard from sleep mode.
- Turn the keyboard off and then back on.
- Recharge the internal battery. For more information, see “Charging the keyboard battery.”
- Verify that Bluetooth is turned on in your tablet's settings (⚙️ **Apps** → **Settings** → **Network connections** section → **Bluetooth**).
- Verify that “TYPE-S” is paired with your tablet (⚙️ **Apps** → **Settings** → **Network connections** section → **Bluetooth**).
- Re-establish Bluetooth connection between the keyboard and your tablet by selecting “TYPE-S” in the list of **Available devices**. The status light on your keyboard turns solid blue when Bluetooth connection is established.

What do you think?

Thank you for purchasing our product.
Please take a minute to tell us what you think of it.

www.logitech.com/ithink



www.logitech.com

www.logitech.com/support/type-s

© 2014 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Samsung, GALAXY and Tab S 10.5 are trademarks of Samsung Electronics Co., Ltd. Android, Google Play and Google Maps are trademarks of Google, Inc. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

621-000350.002